



CARBON CERAMIC DERAILLEUR FOR CAMPAGNOLO EKAR

EKAR 13 SPEED VERSION

TOOLS NEEDED

1. Hex Allen Key 2 mm
2. Torx Key T15
3. Torque Wrench
4. Flat Keys (8 / 30 mm)
5. Chain remover
6. New chain



INSTALLATION VIDEO


For installation tutorial video, please follow the instructions in the "How To Install your Nova Ride Campagnolo Ekar 13 Speed Oversize carbon pulley cage" video to properly mount your new cage on our Nova Ride Youtube channel.

Scan this QR Code to access our installation video and social media.




STEP 1

1. Lock the derailleur.
2. Remove the rear wheel of your bike.
3. Remove the chain by using the chain remover.
4. Shift the derailleur to the biggest sprocket.




5. Unscrew the stopper by using the Hex Allen Key. **The stopper have a reverse thread so unscrew clockwise.**
Set the stopper aside to reuse later.

PLEASE NOTE, the cage is under tension, so you have to hold it well.



6. Clock the cage until there is no tension.



STEP 2


1. Remove the derailleur cover by hand or by using flat key 30 mm.



2. Remove the central nut by using flat key 8 mm. Set it aside to reuse later.



3. Remove the cage, the spring and the dust cover.
4. Remove the spring from the cage. Set aside to reuse later.



STEP 3

1. Remove the cage axle by using the Torx key T15.



2. Install the axle on the Nova Ride cage by using the Torx key T15.



3. Put the spring rod into the low (L), middle (M) or high (H) tension adjuster on the cage.

L Low = Increases performance and lower chain tension

M Middle = Recommended tension hole

H High = Better shifting and higher chain tension



STEP 4

1. Put the Nova Ride cage with the spring in the derailleur.
2. Screw the central nut by using the flat key 8 mm.
3. Tighten the central nut at 2,5 N.m by using the torque wrench.



3. Rotate the Nova Ride cage until you see the stopper screw pitch (circled in red).
4. Screw the stopper back on by using the hex Allen key 2mm.
The stopper have a reverse thread so screw counter clockwise.



5. Reinstall the derailleur cover by hand or by using flat key 30 mm.
6. Shift your derailleur back down to the smallest sprocket.
7. Reinstall your rear wheel.
8. Then refer to the next page for your chain length and derailleur adjustment.



LAST IMPORTANT SETTINGS

To ensure the best riding performance make sure that your new Nova Ride Carbon Ceramic Derailleur cage is mounted correctly.

You can follow the next instructions below or watch our YouTube video tutorial "How To Calculate The Correct Chain Length and Set-up the Gear Shifting": <https://www.youtube.com/watch?v=r1z0D6rfHJA>

CHAIN LENGTH ADJUSTMENT STEPS :

1. The chain length changes because the Nova Ride pulley wheels are bigger. So, it is strongly recommended to use a new chain. We recommend adding 3 to 5 links to your previous chain.
2. Put the chain on the smallest sprocket of your cassette and on the smallest chainring of your crankset.
3. In this configuration, the stopper must not be in contact with the derailleur body. Make sure to let around 1 to 3 millimeters between the two parts.

NOVA RIDE CCD CAGE AND DERAILLEUR ADJUSTMENT STEPS:

1. Put and hold your Nova Ride carbon cage perpendicular to the ground.
2. Then, set with the tension screw the derailleur b-limit gap so that the teeth of the biggest cassette gear is around 5 millimeters from the upper wheel's teeth of your Nova Ride CCD.
3. Now to finish the installation, you only need to check and re-adjust the indexation of your derailleur, this regarding to the Shimano standard and advice.

You are now ready to go! Enjoy your ride with your new Nova Ride Carbon Ceramic Derailleur.

You can review us on Trustpilot : <https://www.trustpilot.com/review/novatoride.com>

MAINTENANCE

No set of rules can be made for how often your part have to be maintained. Our sealed bearings are protected with the alloy covers and enable a longer lifespan. We designed these parts in a way that you will not have to worry about maintenance or technical issues. No lubricants or grease are required to put on the bearings. During your rides, dirt may get between the cover and the bearings, you can remove it with water or a degreaser.

Please note that these are dry bearings, so do not use any lubricant.

WARRANTY TERMS

Nova Ride warrants all products to be free from defects in materials and workmanship. The warranty is effective from the original date of purchase. The warranty covers all Nova Ride products. It is non-transferable and valid to the original purchaser of the product only.

Ceramic Pulley Wheels & Carbon Ceramic Derailleur : 4 years warranty

Any Nova Ride product found to be defective in materials and/or workmanship will be repaired or replaced at the discretion of Nova Ride. It is the sole responsibility of the product's user to inspect and examine the product on a regular basis to determine the need for correct maintenance or replacement.

Not covered under the warranty program : Products determined to be tampered with, modified or neglected, products that have been misused, products in lack of maintenance, products that are subject to normal wear and tear, products affected by a crash or sudden obscure impact, products damaged due to improper installation/reinstallation, products used for any purpose other than the intended use and second hand purchased products.

Fully ceramic sealed bearings so indeed there is no risk of oxidation.

CONTACT

Email for After Sales Service

sav@novatoride.com

Email for Product info

info@novatoride.com

Instagram

nova2ride

Facebook

novaridecomponents

YouTube

Nova Ride

LinkedIn

Nova Ride

ENJOY THE RIDE

